CE

JuLI™ Stage

Automated cell imaging system

NEW PARADIGM FOR CELL BASED ASSAY

User Manual

Copyright © NanoEnTek Inc. All rights reserved.

NanoEnTek

Table of contents

Product components **4**
Product overview **5**
Features **6**
Description **7**
- Front view 7
- Side view 7
- Rear view 8
- Control box 9

Installation **10**
- Unpack the instrument 10
- Remove the filter change lock module 10
- Install the instrument 11
- Place the instrument 13
- Operating environment 14
- Cautions 14

User interface **15**
- GUI 15

Basic operation **17**
- Moving 17
- Selection 18
- Zoom 20
- Focus 21
- Size bar 21

Operation **22**
- Preview menu 22
- Option menu 28
- Data menu 36
- Setting menu 42

Quick operation guide **45**
- Image capture, save and overlay 45
- Multi well default position and auto focus 47
- Manual position set and manual focus 49

Cleaning and Maintenance **51**
Troubleshooting **52**
Warranty **53**
Safety precautions **54**
Product specifications **57**
Ordering information **58**
Technical support **59**

Product components

The JuLI™ Stage, Automated cell imaging system is shipped with the following components.
Please check all components listed below when the instrument is delivered.
PC will be shipped separately because it is optional.

If any item is missed or damaged, contact your local distributor or e-mail sales@nanoentek.com.

JuLI™ Stage main instrument

1 EA

Control Box

1 EA



USB Cables (20 ~ 43 cm)

2 EA



Power cord with 4 adaptor cords

(4 pcs/set, for U.S./Canada/Taiwan/Japan, Europe or UK)

1 SET

Connection Cable

1 EA

Objective lens (4x, 10x, 20x)

3 EA

10x lens is factory-installed with the JuLI™ Stage main instrument.

User manual

1 EA

Quick manual

1 EA



Product overview

A fully-automated, fluorescence live cell imaging system that acquires cell images directly from various cell culture plates (6 to 384 well) and dishes in an incubator. JuLI™ Stage supports multi-channel fluorescent colors, multiple objective lenses, and sensitive filter-based optics to optimize for various live cell assays. In addition, it enables users to support quantified cellconfluence results with low variation and the growth curve using image-based analysis with bright field.

Compact, compatible and automated fluorescence cell imaging system of live cell imaging from inside your cell culture incubator!

Suitable for the following applications:

- Live cell imaging (time lapse)
- Cell culture quality control
- HCS cell imaging analysis (6 to 384 well)
- Cell-based assay optimization
- Image stitching
- Angiogenesis
- Scratch-wound assay
- Neurite growth
- Angiogenesis
- Protein expression
- Kinetic imaging and cell differentiation
- Cell growth monitoring
- Cell culture optimization
- Stem cell development
- Cell proliferation
- Cell cytotoxicity
- Cell migration study
- Cell differentiation



Features

The JuLI™ Stage an automated cell imaging analyzer, offers you the following benefits,

Automated imaging system

The JuLI™ Stage provides a live cell imaging using automatic focus and precise one by one multi-well control system.

- Fully automated and motorized X-Y scanning stage
- Auto focusing on every single position
- Image tiling with a stitching function

Sensitivity and expandability

The sensitive CCD camera, multi-channel fluorescence and magnification (4, 10 & 20 X) provide the powerful detection capabilities required for various cell-based assays.

- High-sensitivity monochrome CCD
- Multi-channel fluorescence imaging (3 color fluorescence (GFP, RFP and DAPI) and bright channel)
- User-changeable objective lens (4, 10 & 20 X)

Versatile and Powerful S/W

The JuLI™ Stage software allows you to generate live cell imaging and analysis easily.

- Image capturing and time-lapse recording with multi-position scanning
- Navigation function to figure out the optimal position
- Image stitching function to scan the whole well at once

Compatibility and easy to use

The compact and ready to use system can be operated in an incubator and it can be controlled by the JuLI™ Stage software from outside.

- Compact and compatible to CO2 incubator
- 23" full HD All-in-one touch screen PC control
- Simple steps for the system setup and operations
- Compatibility with various brands of well plates by auto adjustment function



Description

Front view

Cover	Used to protect test samples from external light. When you use the JuLI™ Stage in an incubator, the cover can block out light from the outside.
Main body	Front view of the JuLI™Stage.The main body is composed of LED, Filters (Fluorescence mode) and optic parts.



[Front view]

Side view

LED (Bright mode)	LED is used for bright image viewer.
Vessel holder	This is a holder for sampling plates. The capacity is 6 well to 384 well.
Automatic X-Y stage	The automatic X-Y stage makes it possible for you to move to the position you want.
Lens holder	This is a holder for changeable lens.



[Side view]

Description

Rear view

Fan	Machinery cooling system.
Connection port	Connect the JuLI™ Stage main instrument with the control box.
Power inlet	Connect the instrument to an electrical outlet using the supplied power cord and the appropriate plug, based on the electrical outlet configuration in your country.



[Rear view]

Description

Control box

Serial and camera LED	When the PC and the control box are properly connected, the red light is turns on.
Connection port	Connect the JuLI™ Stage main instrument with the control box
Serial port	Control the camera in the JuLI™ Stage main instrument.
Camera port	Control the JuLI™ Stage main instrument operating.



Installation

Unpack the instrument

1. Open the box and remove the **material foam** in the box.
2. Carefully lift the instrument out of the box, holding it by handholds in the **bottom of the base.**
3. Place the instrument on a flat, level surface (table or incubator).

⚠ ***IMPORTANT!***

Do not lift the JuLI™ Stage by condense arm.

Remove the filter change lock module

1. Unscrew the **filter change lock module screw** until they spin freely.
2. Gently pull filter change lock module screw out, away from the instrument.





⚠ ***IMPORTANT!***

Remove out the Filter change lock module by turning it counterclockwise to prevent the damage of the instrument **before plugging the power cord into power outlet and turning on the JuLI™ Stage.**

Installation

Install the instrument

1. Connect the **PC** and the **Control box** (Serial port, Camera port) using two **USB cables**. (PC Monitor Resolution: 1920 ×1080 pixels)

☞ *Note: Check the connection on the **rear side** of the PC.*

1-1. Plug the power cord into the rear side of the PC.



2. Connect the **JuLI™ Stage instrument** and the **Control box** and using the **connection cable**.

☞ *Note: Make sure for connection port direction of control box before connecting.*

2-1. Plug the power cord into the **rear** of instrument.



3. Plug the power cord of PC and instrument into the electrical outlet.

☞ *Note: Be sure to use only the power cord supplied with your instrument.*
Powering the instrument with an unapproved power cord may damage the instrument.

Installation

Install the instrument

4. Turn the PC and the Control box on by pressing the **Power button**.

5. Double-click the JuLI™ Stage icon on Desktop. The JuLI™ Stage software starts up.

☞ *Note: The JuLI™ Stage will be ready to use after initialization is completed when power on.*



Installation

Place the instrument into the incubator (or to the table)

Live-cell images from various cell culture dishes are directly captured in a cell culture incubator. This design allows an instrument to be installed in an incubator, and prevents the contamination by maintaining a sterile environment. The intuitive graphic user interface also provides quick and convenient use in a cell culture incubator while capturing time-lapse imaging.

The JuLI™ Stage operates in standard size of incubator. The JuLI™ Stage can be used in both inside and outside incubator.

JuLI™ Stage installed inside of the incubator



JuLI™ Stage installed on the table

⚠ **IMPORTANT!**

Lay a cover if the instrument is installed on the table to protect test samples from external light.

Installation

Operating environment

• Allow at least 10 cm (4 inches) free space at the back of the instrument to allow for proper ventilation and prevent overheating of electronic components.

• Set up the JuLI™ Stage away from direct light sources, such as windows. Ambient room lighting can enter the imaging path and affect the image quality.

• Place the JuLI™ Stage on a level surface away from vibrations from other pieces of equipment.

• Operating temperature range: 5° - 40°C (41° - 104°F)

• Relative humidity range: 20 - 95 %.

Cautions

⚠ **IMPORTANT!**

The JuLI™ Stage is optimized into standard size of cell culture incubator.
It is recommend that the temperature should be stabilized in case of a small size incubator before using the instrument.

Warm up the JuLI™ Stage for 2 hours before monitoring.
The power should be on when warming up the instrument.

The well plate's cover should be wetted by the cell culture media before monitoring.
This step is required to avoid condensation inside the well plate cover for monitoring.

Avoid exposing the JuLI™ Stage to UV light.
UV light may degrade components, including plastics. Damage from UV exposure is not covered under the manufacturer's warranty.

Always wipe the surfaces with ethanol-soaked paper towels.
Do not directly spray ethanol anywhere on the JuLI™ Stage.

User interface

GUI

The JuLI™ Stage software allows you to generate live cell imaging and analysis easily.

- Image capturing and time-lapse recording with multi-position scanning
- Navigation function to figure out the optimal position
- Image stitching function to scan the whole well at once

The JuLI™ Stage is a fully automated imaging system controlled by the integratedthe JuLI™ Stage software. The software, accessed the mouse, controls the automated X-Y axis stage and features imaging and analysis tools.

Preview menu



Optionview menu



User interface

GUI

Data menu



Setting menu



Basic operation

The JuLI™ Stage can be used in combination with PC (Monitor Resolution 1920x1080) which enables users to operate the instrument using the computer mouse and keyboard. The JuLI™ Stage basic operations use the **mouse** for moving, selecting and zooming in/out. The detailed explanations are listed below.

☞ *Note: This manual describes the mouse function in **Default setting (Type 1)**.*
If necessary, you can change the mouse setting type the Setting menu.

Moving

Right mouse

1) Inter well: Moving among wells

Move the stage to the well you want by clicking the Right button of the mouse in both preview and option menu.



The stage is moved from A-1 to A-2 by clicking the right button of the mouse.
The selected well is marked by a yellow circle as shown above.

2) Intra well: Moving within the well

The stage is moved to a position you have selected on the navigation window by clicking the right button of the mouse in both preview and option mode.



The stage focuses in the center of the well when the well is selected. The selected image is marked by **red square** when the specific spot is selected by clicking the right button of the **mouse**.

3) Moving in view

The stage is moved to the spot you assigned in the view field by **Dragging** with the **right button** in both preview and option mode. The moving distance is marked by a red line as below.



Basic operation

Selection

Left mouse

1) Selecting well

The well is marked by a grey color when the specific well is selected by clicking The **Left button**. Click once to select and click once more to deselect.

☞*Note: The JuLI™ Stage supports selecting function only in the **Option menu.***
*The selecting function does not work in the **Preview menu**.*



None of 24wells is selected



The selected well **A-1** is marked by a **grey color** by **pressing** the **specific well.**



The **first well line** is marked by a grey color when **pressing line 1.**



The "A" well line is marked by a grey color when **pressing line A.**

☞ *Note: Deselection: **Select** each well again or **drag** the selected wells with the **Shift key** on the keyboard.*



Select any well or any well lines with the left mouse button by **dragging.**

☞ *Note: Deselection: **Select** each well again or **drag** the selected wells with the **Shift key** on the keyboard.*

Basic operation

Selection

Left mouse

2) Selecting position

When the specific position well is selected by clicking the **Left button**, the assigned position is marked by **Green square** in the Navigation window. Press the **Position set button** in order to confirm.
The JuLI™ Stage supports the multi-selection functions.



None of the positions in the Navigation window are selected.





The **Green square** appears in the center of the well when pressing the **Default button.**



The JuLI™ Stage allows users to select **more than one position** in a well by clicking the **Left button.**



Press the **Position set button** to save your setting that the green square will change to a **Red square**.

< Overlapped positions >

⚠ **IMPORTANT!**

If the two selected positions are overlapped, The JuLI™ Stage only assigns previous one.
i.g. Two green squares (overlapped) -> Position Set button -> One red square.

Basic operation

Zoom

Mouse wheel
(Up and down)

1) Zoom-in

Scroll up in the view field to use the zoom in the image.
The JuLI™ Stage supports zoom-in function in both the real view and captured images that allows users to magnify specific position by scrolling up.



2) Zoom-out
After zooming in, **Scroll down** to zoom out the view field in both real view and captured images

Basic operation

Focus

Mouse wheel
(Up and down)

3) Focus adjustment

Scroll up or down with **Shift key** on the keyboard for fine focus adjustment.
It is a same function with the **Fine focus interface** in the menu



☞ *Note: Coarse focus function is in the menu. It is not supported by using the mouse wheel.*

Size bar

4) Size bar

The JuLI™ Stage enables users to check **Sample size** and moving distance by **wheel dragging.**

☞ *Note: The size bar function is supported in the both Preview and Option menu.*



Operation

Preview menu

The **Preview menu** allows you to select basic system functions and is the first screen after start-up. It is available for checking the sample, setting the optimized focusing, capturing and merging the images.



Operation

Preview menu
Vessel type

1. Press the **Vessel button**.
2. Select the **Vessel type,** which is used for selecting the sample vessel category.
3. Press the **Vessel button** again to close the window without calibration.

Vessel calibration

1. Press the **Calibration button**, if necessary.
2. Set the calibration options from up to bottom.
   Step 1) Move to A1 and check the A1. Set the calibration options by checking the up and down/ bilateral symmetry.
   Step 2) Move to A2 and check the A2. Set the calibration options by checking the up and down/ bilateral symmetry.
3. Press the Close button to exit.


1. Move to A1 well.-> Check image from all direction.-> Fix the position.
2. Move to A2 well.-> Check image from all direction.-> Fix the position.
3. Press Save to exit.
OK



Focus information

1. Press the **Focus information button.**
2. The focus information button is designed to provide the focus setting information about each well.
   e.g. A1: Complete Bright focus
   A2: Complete Bright and GFP focus
   A3: Complete Bright, GFP and RFP focus



Operation

Preview menu
Map mode

1. Press the **Map mode button**.
2. Press the **Map option button** which will appear after pressing the **Map mode button**.
3. Select the LED channel and image size, and check whether or not to use auto focus function.
4. Press the **Make a Map button**.
5. Press the **Cancel button** to return to previous screen without setting.
6. **Load map button** will be activated after finishing the map making.
7. Refer to Quick guideline for more details (page 45).

Navigation window

1. Preview well is marked by a **Yellow circle.**
2. The field you selected is marked by the **Red square** in the Navigation step.

☞ *Note: The size of red square, which is field of view, depends on vessel type.*





24 well plate





96 well plate

LED channel

1. Select one of the **LED channels** which will be applied in the preview.
2. Click other buttons to change LED channel, if necessary.
3. Click the button you selected once more to turn off.

Operation

Preview menu
Camera set

Camera setting allows users to customize the user interface within the range of setting values. To adjust the illumination intensity, use the Exposure and Brightness bar. To adjust the power of light sources, use the LED power bar.

- Exposure range : 5 ms ~ 500 ms
- Brightness range : 0 ~ 40
- LED power range : 1 ~ 10



Focus

Focus menu is used for finding the position of sample easily and supports both Auto and Manual Focus.

1. Quick focus slide: Click to use quick investigation function.
2. Adjust the focus using the **Coarse** and **Fine focus button.**



☞ *Note: **Scroll up or down** with **Shift key** on the keyboard for fine focus adjustment.*

Auto focus

Press the **Auto Focus button** after checking the contours of cells which appeared.

Manual Focus

1. Adjust the best focus by pressing the **Fine Focus button.**
2. Press the **Manual Focus button.**
3. Press the **OK button** when the pop-up window appears.
4. Check the information about manual focus setting by the **Focus button.**



☞ *Note: The optimal focusing position is suggested by the JuLI™ Stage Auto Software. Manual focus is also available if the suggested focusing position is not optimal.*

Operation

Preview menu
Capture image

Press the **Capture button** to capture the image.



Save image

Press the **Save button** to save the **captured image.**
Enter the file name and store the path when the pop-up window appears.



Confluence

Press the **Confluence button** to check the confluence value in the bright field. The JuLI™ Stage supports two kinds of parameters (**Sensitivity and Background level**) which users are able to choose from A ~ C type.





Parameter	Cell line	Recommendation
A(Default)	HepG2, GH3, Hep3B, A549, MCF7, SH-SY5Y, SCN2.2, NIH-3T3, F9, HeLa, DU-145	Sensitivity level 9 Background level 2
B	LNCaP	Sensitivity level 10 Background level 2
C	U-2 OS ADSC	Sensitivity level 10 Background level 8

Operation

Preview menu
Overlay image

1. Capture images from **more than two channels**. (Bright, GFP, RFP or DAPI).
2. Press the **Overlay button**, then the editing window will appear.
3. Press the **Save button** in the overlay window to save the overlapped image.



Stage moving control

Press the **Stage moving control button** to control the X-Y stage position.



☞ *Note: The stage is also moved to the spot you assigned in the view field by **Dragging with right button of the mouse**.*

Minimum & Exit button

Minimize window or close the operation program using the **Minimize** and the **Close button.**



Operation

Option menu
Camera setting option

The **Option menu** allows you to set the sample monitoring options. It is composed of two parts (**Camera setting and Monitoring setting option**).
Camera set part contains detailed functions such as assigning well/specific position, camera setting and focus settings (auto focus, point to focus and manual focus).

☞ *Note: The functions and buttons commonly used in **Preview menu**, Please refer to the details in Preview menu section.*



Operation

Option menu

Navigation position set

- **Position set** : Once **Position set button** is pressed after assigning an area you want, the area will be changed into **Red square** at navigation window.
- **Default button** : Select well and then press **Default button**, center value of well will be assigned. If you want to assign the area, press the **Position Set button.**
- **Undo button** : When you want to **Cancel the specified location** with the **Right Mouse button,** specified locations are cancelled chronologically from the most recent specified location.
- **Clear button** : Delete all of the set values in the well (navigation window).

Camera option tap

Press the **Camera Tap button** to select the option.





Manual Focus

Manual Focus Toggle button is used during the monitoring.
In this case, Auto focus toggle button is set "off" automatically.

Auto Focus

Auto Focus Toggle button is used during the monitoring.
In this case, Manual focus toggle button is set "off" automatically.



Point to Focus

This button activates **Auto Focus in all area**, in case of several areas shooting in one well. This button is only activated when auto focus toggle button is set "**On**".



Operation

Option menu
Focus offset

Focus offset is used to **revise the focus** if the auto-focus function does not provide optimal focus results corresponding to your sample. This is more convenient to operate in comparison with manual focus function.

Focus offset button can be used when auto focus mode is **turned on.**
This allows a user to set specific range of revision when there are differences among channels.



Steps are as below.

1. Adjust the focus according to your sample, and then press the **Focus Offset button** (When the autofocus mode is **turned on**).

2. The JuLI™ Stage Software automatically adjusts the **Optimal focus** corresponding to your sample in the bright field.

3. If necessary, edit the focus using the **Fine focus button** and then press the **Set button** to confirm. (The JuLI™ Stage automatically has memory for z-value; distance between auto-focused and a user moved position).

4. Select the channel using the **LED channel bar.**

5. Edit the focus following step 3 and then press the **Set button.** The z-value will be displayed.

6. If necessary, follow step 4 ~ 5 in different LED channel.

☞ *Note: Focus offset may not provide optimal focus when sample is damaged.*

Operation

Option menu
Monitoring setting option

Monitoring set part provides various setting functions to **assigning tile**, setting detailed **monitoring condition** (interval and cycle) and setting **image format.**

☞ *Note: The functions and buttons commonly used in **Preview menu**, Please refer to the details in Preview menu section.*



Operation

Option menu
Monitoring option tap

Move among options using the **Setting Tap.**

⚠ **IMPORTANT!**

Warm up the JuLI™ Stage for 2 hours before monitoring.
The power should be on when warming up the instrument.



The well plate's cover should be wetted by the cell culture media before monitoring.
This step is required to avoid condensation inside the well plate cover for monitoring.

The 15 minutes of time interval is recommended to prevent from cell damage.
The cell may be damaged by LED less than 15 minutes interval in the case of monitoring in Bright & GFP mode. However, the optimal time interval depends on cell lines.

Title name

To start monitoring, assign the title using the pop-up keyboard.



LED channel

Select the channel using the **LED channel bar.**

Stitching option

Press the **Stitching toggle button** to apply stitching while monitoring.
Set the **Range of stitching** (2 X 2 ~ 10 X 10, 4 ~ 100 images.)



Growth curve option

Press the **Growth curve toggle button** to make growth curve while monitoring.
The growth curve can be recalculated when editing data. To make the growth curve, set the confluence parameters in the camera set part (Refer to page 28).

Operation

Option menu
Wound healing option

Press the **Wound healing** toggle button to make wound healing curve.
The wound healing curve can be recalculated when editing data.
To make the growth curve, set the confluence parameters in the camera set part (Refer to page 28).



Confluence parameter

Once **Confluence parameter button** is selected, the setting window will be shown up. After parameter is modified, press the **Apply button** to see image



Image format

Image format can be saved as 4 types of file. One type of file can be selected at a time.



Time set & Mode

- **Total time**: Is not modified at this window and is displaced by calculating of interval time and cycle.



- **Interval time**: When a well is selected, **estimated time** shows up with red color depending on selected condition. With reference select interval time. The interval time can not be set **shorter** than the **red estimated time**.



- **Cycle**: Select number of image in each position.



☞ *Note: You can edit the monitoring cycle while monitoring by pressing* **Pause button**.
The new cycle value that you will enter is longer than the ***current cycle***.

When Each bar is double-clicked, the interval and cycle setting key pad shows up.

⚠ IMPORTANT!

The 15 minutes of time interval is recommended to prevent from cell damage.
The cell may be damaged by LED less than 15 minutes interval in the case of monitoring in Bright & GFP mode. However, the optimal time interval depends on cell lines.

Operation

Option menu
Start button

Press the **Start button** to move to the next step.

Cancel button

Press the **Cancel button** to reset.

Ready to start

Ready to start window shows all setting information you assigned.
Press the **Play button** to start program after checking the settings.



☞ *Note: You can edit the monitoring cycle while monitoring by pressing* ***Pause button.***
The new cycle value that you will enter is ***longer than the current cycle.***

Operation

Option menu
Graph data

The **Graph button** shows all graphs so far while the instrument is working.



Confluence table

The **Confluence Table button** provides back data sheet of Graph.



Plate	Point	Image	Bright Cell Area(m...	Bright Cell (%)	GFP Cell Area(mm...	GFP Cell (%)	RFP Cell Area(mm...	RFP Cell (%)	DAPI Cell Area(mm...	DAPI Cell (%)
A01	000001	000001	4.06	07.00	.00	00.00	.00	00.00		
A01	000001	000002	2.77	04.78	.00	00.00	.00	00.00		
A01	000001	000003	2.79	04.81	.00	00.00	.00	00.00		
A01	000001	000004	2.99	05.15	.00	00.00	.00	00.00		
A01	000001	000005	3.07	05.29	.00	00.00	.00	00.00		
A01	000001	000006	3.19	05.49	.00	00.00	.00	00.00		
A01	000001	000007	3.47	05.98	.00	00.00	.00	00.00		
A01	000001	000008	3.55	06.11	.00	00.00	.00	00.00		
A01	000001	000009	3.77	06.49	.00	00.00	.00	00.00		
A01	000001	000010	3.93	06.77	.00	00.00	.00	00.00		
A01	000001	000011	3.99	06.87	.00	00.00	.00	00.00		
A01	000001	000012	4.17	07.19	.00	00.00	.00	00.00		
A01	000001	000013	4.33	07.47	.00	00.00	.00	00.00		
A01	000001	000014	4.32	07.45	.00	00.00	.00	00.00		
A01	000001	000015	4.43	07.63	.00	00.00	.00	00.00		
A01	000001	000016	4.52	07.79	.00	00.00	.00	00.00		
A01	000001	000017	4.58	07.89	.00	00.00	.00	00.00		
A01	000001	000018	4.58	07.90	.00	00.00	.00	00.00		
A01	000001	000019	4.65	08.02	.00	00.00	.00	00.00		
A01	000001	000020	4.73	08.16	.00	00.00	.00	00.00		
A01	000001	000021	4.87	08.40	.00	00.00	.00	00.00		
A01	000001	000022	4.90	08.45	.00	00.00	.00	00.00		
A01	000001	000023	4.94	08.52	.00	00.00	.00	00.00		
A01	000001	000024	4.97	08.57	.00	00.00	.00	00.00		
A01	000001	000025	5.08	08.76	.00	00.00	.00	00.00		
A01	000001	000026	5.23	09.01	.00	00.00	.00	00.00		
A01	000001	000027	5.27	09.09	.00	00.00	.00	00.00		
A01	000001	000028	5.16	08.90	.00	00.00	.00	00.00		
A01	000001	000029	5.28	09.10	.00	00.00	.00	00.00		
A01	000001	000030	5.28	09.10	.00	00.00	.00	00.00		
A01	000001	000031	5.36	09.24	.00	00.00	.00	00.00		
A01	000001	000032	5.35	09.22	.00	00.00	.00	00.00		
A01	000001	000033	5.50	09.48	.00	00.00	.00	00.00		
A01	000001	000034	5.58	09.61	.00	00.00	.00	00.00		
A01	000001	000035	5.68	09.79	.00	00.00	.00	00.00		
A01	000001	000036	5.72	09.85	.00	00.00	.00	00.00		
A01	000001	000037	5.67	09.78	.00	00.00	.00	00.00		
A01	000001	000038	5.70	09.83	.00	00.00	.00	00.00		
A01	000001	000039	5.62	09.69	.00	00.00	.00	00.00		
A01	000001	000040	5.71	09.84	.00	00.00	.00	00.00		
A01	000001	000041	5.75	09.91	.00	00.00	.00	00.00		
A01	000001	000042	5.77	09.95	.00	00.00	.00	00.00		
A01	000001	000043	5.99	10.32	.00	00.00	.00	00.00		
A01	000001	000044	5.98	10.31	.00	00.00	.00	00.00		
A01	000001	000045	6.02	10.38	.00	00.00	.00	00.00		
A01	000001	000046	6.06	10.44	.00	00.00	.00	00.00		
A01	000001	000047	6.05	10.43	.00	00.00	.00	00.00		
A01	000001	000048	6.12	10.55	.00	00.00	.00	00.00		
A01	000001	000049	6.19	10.67	.00	00.00	.00	00.00		
A01	000001	000050	6.23	10.74	.00	00.00	.00	00.00		
A01	000001	000051	6.41	11.04	.00	00.00	.00	00.00		

Operation

Data menu

Data menu provides the function to view and edit the captured images. In the data menu users are able to check, edit data (cell growth curve, wound healing) and make a movie.

Once you selected the title, the JuLI™ Stage shows test conditions including vessel type, well captured position, LED channel condition, interval time and cycle number.



Operation

Data menu

Title list

The selected title is marked by green color when clicking a title.



Vessel display

The color of vessel contains information about test conditions.

- Grey circles: Captured well
- Red circles: Captured well and selected for review



LED set & Navigation display

LED set & Navigation display contain the **condition of LED channel and position** of captured images. The JuLI™ Stage can hide or open information by pressing the **LED channel buttons.**

The captured position is marked by **Red square** as below. Click the red square to check the images in detail.



Operation

Data menu
Time set & Mode

Time setting condition and the mode information are displayed



Display data

Press the **Display Data button** (**Graph and Confluence table**) to check growth curve and confluence data.

Display data contains the **Graph** and **Confluence table button** that open related information. For example, press the graph button to check the wound healing and growth curve.

☞ *Note: If the growth curve or the wound healing mode is not selected in option menu, the button may not be activated. If necessary to obtain growth curve data, you can edit confluence data table in Edit mode.*

Display export

Press the **Export button** to export the captured images. The multiselection function is supported.



☞ *Note: Can access or download the image data through* ***JuLI™Stage / TIMELAPS folder*** *in PC also.*

Display edit

Press the **Edit button** to get additional analysis and data with test results.
(described in next page for more details)

Operation

Data menu
Data edit

Edit operation allows users to get additional analysis and data with test results.
This Editing operation mode gives you excellent imaging function to **overlay image & movie and reset confluence parameter** for more accurate growth curve.

Overlay option

Edit the **parameters** in overlay tab of Edit menu according to your test condition. Press the **Save button** and assign title and storing path.





Operation

Data menu

Overlay movie save as

Edit the parameters in overlay tab of Edit menu and move to the **Movie tap.**

1. **Title**: Click the **Title bar** and type the title and storing path.
2. **Frame rate**: Choose one of the frame rates. (1, 5, 10, 15 or 20 fps)
3. **Running time**: Expected running time depends on numbers of images in folder and frame rate.
4. **Make movie** : Press the **Start button** to make a movie
5. **AVI file** will be created in storing path you assigned.





Operation

Data menu
Growth curve save as

1. Select tile of existing data to make growth curve and click the **Edit button.**
2. Edit the **parameters** in the **Graph tap** to set the optimal condition for confluence.
3. Wound healing mode: Turn on the **wound healing toggle button**, if necessary.
4. Press the **Make a graph button** to check vessel images
5. Select the **Well** and **LED channel** and Press the **Apply button.**









Operation

Setting menu

Setting menu contains information about the JuLI™ Stage as well as several user preference and other Settings. Setting menu allows users to edit settings about the software & firmware information and basic operations.



Operation

Setting menu

Version Auto check

The JuLI™ Stage checks for **the latest version of software or firmware** and automatically display the information window whenever it starts up. This is available only for PC with **internet connection.**

Software information

Software information is used to **update** through the USB drive and network connection.



Firmware information

Firmware information is used to **update** through the USB drive and network connection.



☞ *Note: Press **Update button** if you have the update file for the software or firmware. Or press **Check button** and then **Update button** if the PC has a internet connection for updating.*

Lens information

Provides lens information when it moves and checks the size. The lens can be changed by hands and the size of field of view (square) on navigation window is also changeable as lens information.

Changing lens

1. Move the X-Y stage to the center position using the Stage moving control button.
2. Loosen and rotate the current lens counterclockwise to remove it from the holder.
3. Place the new lens on the holder and rotate clockwise. Be sure to rotate the objective until it is tight in the holder.



Operation

Setting menu

Data path & system info

Allows users to assign the save path and check disk volume



Mouse type

Mouse control is used for changing basic function of mouse.



☞ *Note: Type 1 is factoring setting. Can change the type, if necessary.*

Serial info

Shows serial number of the JuLI™ Stage main instrument.

Admin mode

Administration mode. It is for manufacturing engineers to set the system.



Quick operation guide (Image capture , save and overlay)

1. Select the **Preview menu.**

2. Press the **Vessel button.**

3. Select the **Vessel type** according to your sample when well type list appears.



4. Check the **selected Vessel type** and press **Vessel button** again to finish setting.



5. Move to the well and position you want using the right button of mouse. You can check the vessel image and the moving state in the navigation window and view field.



6. Select the **LED channel** for capturing images.

7. Adjust **Exposure, Brightness and LED Power,** if neccessary.



8. Find optional focus and adjust with **Focus bar & buttons**



9. Press the **Capture button** to start capturing images.

10. Press the **Save button** to save the captured images, if necessary.

11. Once pop-up window appears, assign the storing path and file type, and press the **Save button** to confirm.



12. If necessary to capture additional images in different channel, select **other LED channel.**

13. Follow Step 6 ~ 10 repeatedly and save images for each channel.

14. After pressing the **Overlay button**, the overlapped images, which captured in each channels, will be displayed.

15. When Overlay button opens the Overlay setting window, edit parameters according to your preference. And then press the **Save button** to follow step 10 ~ 11(The images will be saved as).



Quick operation guide
(Multi well default position and Auto focus)

1. Select the **Option menu** and the camera tap will be activated.

2. Activate the **Vessel button** by pressing.

3. Select the **Vessel type** according to your sample when well type list appears.

4. Check the **selected Vessel type** and press **Vessel button** again to finish setting.



5. Select the **LED channel.**

6. Adjust **Exposure, Brightness and LED Power,** if neccessary.



7. **Select areas** you want to capture by dragging with left mouse button.



8. The selected wells are changed to **Grey color**.



9. Press the **Default button** to equally capture central position of all wells.

10. The assigned position is marked by **Green square** on the navigation window.



11. Press the **Position set button** to complete setting that the green square is changed to **Red.**





12. Press the **OK button** when pop-up window appears.



13. Once the wells are finally confirmed, they are changed to **Red color**.



14. Turn on the **Auto focus toggle button.**



15. Select the **Setting tap** of monitoring option.

16. Refer to the detail options of **Monitoring option tap** in the **Option menu** (page. 32)

Quick operation guide (Manual position set and Manual focus)

1. Click a well you want to capture using right mouse button.



2. Once the well is selected, the X-Y stage is automatically moved to center of well. Move to position you want using right mouse button, and check where you moved to within the navigation window.



3. Press the **Manual focus toggle button.**



4. Select **LED channel**.

5. Adjust **Exposure, Brightness and LED Power,** if neccessary.



6. Find optional focus adjusting the **Focus bar and buttons.**



7. **Manual Focus button** is used to assign optional focus per each position. After setting the focus of each position, press, the **Manual Focus button** to save setting value.

8. If necessary to set manual focus in other channel, press the LED button and follow previous step 4 ~ 7.

9. After adjusting focus and assigning position, press the **Position Set button.**

10. Press the **OK button** when the pop-up window appears.





11. Once the wells are finally confirmed, they are changed to **Red color**.



12. If necessary to set manual focus in other well, follow the previous step 1 ~ 11.

13. Select the **Setting tap** of monitoring option.



14. Refer to the detail options of **Monitoring option tap** in the **Option menu** (page. 32)

Cleaning and Maintenance

Clean the surface of the JuLI™ Stag with a damp cloth. To clean the LCD screen, turn off the JuLI™ Stage, disconnect the power cable, and clean the LCD screen with a soft cloth lightly moistened with LCD cleansing detergent. Cleaning the screen with excessive force can damage the LCD screen.

If liquid spills on the JuLI™ Stage, turn off the power immediately and wipe dry.

The JuLI™ Stage™ does not need regular maintenance. To troubleshoot problems with the JuLI™ Stage™, contact Technical Support (Refer to page 58).

⚠ **IMPORTANT!** ***Never disassemble or service the JuLI™ Stage by yourself.***

Unauthorized repairs may damage the JuLI™ Stage or alter its functionality, which will void your warranty. Contact ***sales@nanoentek.com*** *or your local the JuLI™ Stage distributor to arrange for service.*

⚠ **IMPORTANT!** ***The JuLI™ Stage is optimized into standard size of cell culture incubator.***

It is recommend that the temperature should be stabilized in case of a small size incubator before using the instrument.

⚠ **IMPORTANT!** ***Warm up the JuLI™ Stage for 2 hours before monitoring.***

The power should be on when warming up the instrument.

⚠ **IMPORTANT!** ***The well plate's cover should be wetted by the cell culture media before monitoring.***

This step is required to avoid condensation inside the well plate cover for monitoring.

⚠ **IMPORTANT!** ***Avoid exposing the JuLI™ Stage to UV light.***

UV light may degrade components, including plastics. Damage from UV exposure is not covered under the manufacturer's warranty.

⚠ **IMPORTANT!** ***Always wipe surfaces with ethanol-soaked paper towels.***

Do not directly spray ethanol anywhere on the JuLI™ Stage.

Troubleshooting

Intstallation	
JuLI Stage does not power up	• Check on/off switch on back side of main device. • Check power source or contact your distributor.
LCD screen is black	• Move the mouse. • Check if power supply is connected and power switch is on. • Reset the power button.
Monitoring	
Poor image (Too dark and too bright)	• Re-optimize the brightness and exposure value. • Reset the power button
Dirty image	• Swipe the stage with cotton swab carefully. • Eliminate any dust on the culture dish. • Check for and remove any condensation on thelid of the culture dish.
Time-lapse images become dark or bright	• **Warm up the instrument for 2 hour before monitoring.** (power should be on when warming up the instrument) • **Cell culture flask should be wetted by the culture media before making a movie.** • Eliminate any dust on the culture dish. • Remove any condensation on the lid of the culture dish. • To prevent any problem such as shaking of culture dish or inflowing light, pay special attention when you open or close incubator door during monitoring.
Problem for saving movie file	• Check available volume of the hard disk.

Warranty

NanoEnTek provides 1-year warranty service for defects of material and workmanship.

If any defects occur in the JuLI™ Stage, NanoEnTek provides free repair service for the defective parts at its discretion.

The following defects, however, are specifically excluded:

1. Defects caused by improper operation.
2. Repair or modification done by anyone other than NanoEnTek or an authorized agent.
3. Damage caused by substituting alternative parts.
4. Use of fittings or spare parts supplied by anyone other than NanoEnTek.
5. Damage caused by accident or misuse.
6. Damage caused by disaster.
7. Corrosion caused by improper solvent or sample.

For your protection, the JuLI™ Stage units being returned must be insured against possible damage or loss. NanoEnTek cannot be responsible for damage incurred during shipment
of a defective instrument. It is recommend that you save the original packing material in which the instrument was shipped. This warranty is limited to the replacement of defective products.

For any inquiry or request for repair service, contact **sales@nanoentek.com** or your local distributor.

Safety precautions

Review and follow the safety instructions below :

- If water or other material enters the instrument, adaptor, or power inlet, disconnect the power cord and contact a service person. For operating environment, refer to Product Specifications.
- Do not touch the main plug or power cord with wet hands.
- Always ensure that the power supply input voltage matches the voltage available at your location.
- This instrument is air-cooled and its surfaces may become hot during operation.
  During installing, leave a space of more than 10 cm (4 inches) around the instrument and do not place any objects between the instrument and the walls.
- Do not install the instrument on a slant or a place prone to vibrations, which induces he risk of instrument malfunction or damage of the instrument.
- Never insert any objects into the air vents of the instrument as this could result in electrical shock, personal injury, and equipment damage.
- Plug the power cord firmly into the wall outlet and AC adapter.
- To avoid potential shock hazard, make sure that the power cord is properly grounded.
- Be sure to position the equipment such that it is easy to disconnect.
- Turn off the instrument before unplugging the power cord and/or moving the instrument.
- If the instrument is dropped or broken, disconnect the power cord and contact a service person.
  Disassembly of case will void warranty.
- Use only authorized accessories (adaptor, power cord, and USB drive).

⚠ Warning

Class A equipment is intended for use in an industrial environment. In the documentation for the user, a statement shall be included drawing attention to the fact that there may be potential difficulties in ensuring electromagnetic compatibility in other environments, due to conducted as well as radiated disturbances.

Consignes de securite

Examinez et suivez les consignes de securite ci-dessous :

- N'installez pas l'instrument dans un endroit humide comme une serre ou un incubateur pour eviter un risque de choc electrique. Si de l'eau ou tout autre materiau penetre dans l'instrument, l'adaptateur, ou l'entrees d'alimentation, debranchez le cordon d'alimentation et contactez un technicien de service. Pour l'environnement d'exploitation, reportez-vous aux specifications du produit.
- Ne touchez pas la fiche ou le cordon d'alimentation principale avec les mains mouillees.
- Assurez-vous toujours que la tension d'entree d'alimentation correspond a la tension disponible dans votre endroit.
- Cet instrument est refroidi a l'air de sorte que ses surfaces peuvent devenir chaudes pendant le fonctionnement.
- Lors de l'installation de l'instrument, laisser un espace de plus de 10 cm (4 pouces) autour de cet instrument et ne placez aucun objet entre l'appareil et le mur.
- N'installez pas l'instrument sur une pente ou un endroit soumis a des vibrations, ce qui induit le risque de dysfonctionnement ou d'endommagement de l'instrument.
- N'inserez jamais aucun objet dans les orifices d'aeration de l'instrument, car cela pourrait entrainer un choc electrique, des blessures chez les utilisateurs et des dommages d'equipement.
- Branchez le cordon d'alimentation fermement dans la prise murale et l'adaptateur secteur aussi.
- Pour eviter un risque potentiel de commotion electrique, assurez-vous que le cordon d'alimentation est correctement mis a la terre.
- Assurez-vous de positionner l'instrument de telle sorte qu'il soit facile de debrancher l'instrument.
- Eteignez l'instrument avant de debrancher le cordon d'alimentation et / ou de deplacer l'instrument.
- Si l'instrument est casse ou qu'il soit tombe, debranchez le cordon d'alimentation et contactez un technicien de service. Ne demontez pas l'instrument et la garantie sera annulee en cas de demontage.
- Utilisez uniquement les accessoires autorises (l'adaptateur, le cordon d'alimentation, et le lecteur USB).

⚠ Warning

Le produit de classe A est conçu pour l'utilisation dans un environnement industriel.
Dans la documentation de l'utilisateur, la déclaration doit être incluse pour attirer l'attention sur le fait qu'il peut y avoir des difficultés potentielles pour assurer la compatibilité
électromagnétique dans d'autres environnements, en raison des perturbations rayonnées et conduites par l'électricité.

Safety precautions

Review and follow the safety instructions below :

Symbol	Meaning
	Caution and Warning
	Protective earth (Ground)
CE	This instrument and consumables conforms to the EC Declaration of Conformity.
FCC Compliance	This equipment has been tested and found to comply with the limits for a Class A digital instrument, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instruction manual, may cause harmful interference to radio communications. Operation of this equipment in a residential area is likely to cause harmful interference in which case the user will be required to correct the interference at his own expense.

Product specifications

Items	Specification
Light source	Blue, Green, UV LED (Intensity adjustable)
Objective lens	4 X, 10 X & 20 X (Olympus) + Digital Zoom
Fluorescence	3 fluorescence DAPI: Excitation 390/40, Emission 452/45 GFP: Excitation 466/40, Emission 525/50 RFP: Excitation 525/50, Emission 580LP
Camera	High-sensitivity monochrome CCD (Sony sensor 2/3") 1,936 x 1,456 pixels (2.8 M), 53 FPS, 14 bit
Stage	Automated X-Y-Z Stage Ex-changeable vessel holders
Exported formats	Image: JPEG, PNG, TIFF, BMP Movie: AVI Raw data: CSV
PC requirement	OS Widows Vista or more Monitor (Resolution 1920 x 1080 pixels)
Operating power	100 – 240 V, 1.5 A, 50/60 Hz
Electronic input	12VDC, 5.0A
Dimensions	429 (W) X 310 (D) X 324 (H) mm
Weight	18.0 kg / 39.7 lbs
Operating environment	5 - 40 ℃, 20 - 95 %

Ordering information

Cat. No.	Description	Contents
JS1000S	JuLI™ Stage Starter pack	JuLI™ Stage basic set (JS1000), All-in-one touch screen PC (JS0100),3 Objective lens (4X, 10X, 20X)
JS1000	JuLI™ Stage, Automated cell imaging system	Main device, Power supply, Control box
JP0100	JuLI™ Stage, All-in-one touch screen PC	CPU: Intel Core i5-4590S Processor (Qual Core, 6MB, 3.00GHz) OS: Genuine Windows 8.1 64bit (ENG) RAM: 8 GB (2x4 GB) 1600MHz DDR3L Memory HDD: 1TB 2.5" SATA (5,400 Rpm) 23" Full HD (1920 X 1080) with touch screen
JP0150	JuLI™ Stage, External hard disk rive (Optional)	Total 8 TB (4 TB x 2 ea)
JO0004	JuLI™ Stage, Objective lens (4 X) (Optional)	Magnification: 4 X, NA: 0.16
JO0010	JuLI™ Stage, Objective lens (10 X) (Optional)	Magnification: 10 X, NA: 0.3
JO0020	JuLI™ Stage, Objective lens (20 X) (Optional)	Magnification: 20 X, NA: 0.45

Technical support

Visit our Website at **www.nanoentek.com for :**

- · Technical resources, including manuals, FAQs, etc.
- · Technical support contact information
- · Additional product information and special offers.

For more information or technical assistance, please call or email.

NanoEnTek Inc. (HQ)
12F, 5, Digital-ro 26-gil, Guro-gu, Seoul, 152-740, Korea
Tel : +82-2-6220-7940
Fax : +82-2-6220-7721

NanoEnTek USA Inc.
5627 Stoneridge Drive Suite 304, Pleasanton, CA 94588, USA
Tel : +1-925-225-0108, +1-888-988-0108(Toll free)
Fax : +1-925-225-0109

Email
sales@nanoentek.com

Website
www.nanoentek.com

All the materials in this user guide are protected by Korean and international copyright laws. They cannot be reproduced, translated, published or distributed without the permission of the copyright owner.

JuLI™ Stage User Manual

Website : www.nanoentek.com
E-mail : sales@nanoentek.com

Manufactured by : NanoEnTek Inc. (HQ)
12F, 5, Digital-ro 26-gil, Guro-gu, Seoul, 152-740, Korea
Tel : +82-2-6220-7940
Fax : +82-2-6220-7721

The information in this manual is described as accurately as possible. The changes involved in firmware and software may be applied without notification.

Copyright ©2014 by NanoEnTek Inc. All rights reserved. Published in Korea.

Documentation: NESMU-JST-001E

Revision history: V.0.0 Date: OCT 2014

JuLI™ Stage

Automated cell imaging system

NESMU-JST-001E (V.0.0)

NanoEnTek

NanoEnTek Inc. (HQ)
5, Digital-ro 26-gil, Guro-gu, Seoul, 152-740, Korea

Tel : +82-2-6220-7940
Fax: +82-2-6220-7721

NanoEnTek USA Inc.
5627 Stoneridge Drive Suite 304, Pleasanton, CA 94588, USA

Tel : +1-925-225-0108, +1-888-988-0108(Toll free)
Fax: +1-925-225-0109

Email
sales@nanoentek.com

Website
www.nanoentek.com